ROBOROUGH STUDIOS STRAND LIGHTING 530 LIGHTING CONTROL CONSOLE

BASIC OPERATION

Turning channels on

2 5 ON (channel 25 to FULL)
2 8 [WHEEL] (fade in 28 on wheel)
4 3 @ 6 * (channel 43 to 60%)

2 1 + 2 5 + 28 @ 8.2 * (channels 21, 25 and 28 at 82%)
1 8 THRU 2 4 @ 5 * (channels 18 through to 24 to 50%)

Turning channels off

1 8 @ 0 (channel 18 to 0%) 1 8 @ * (channel 18 to 0%)

All channels off (shortcut)

* @ . (star at point) (all channels to 0%)

Copying channel levels

9 @ COPYFROM 5 * (copies levels of intensity from channel 5 to channel 9)

Recording lighting states ("cues")

CUE 1 0 2 RECORD (record current lighting state as cue 102) (press RECORD twice to overwrite an existing cue)

Note: Cue 0 is always a blackout cue and cannot be modified, but can be played back. Cue numbers can go from 0.1 to 999.9

Setting text for Cues

CUE 1 TEXT House Lights * (gives Cue | the text 'House Lights')

Changing cue times

CUE 1 0 7 TIME 5 * Sets the time on Cue 107 to 5 seconds up and down.

CUE 5 7 TIME 5 / 8 * Sets the time on Cue 57 to 5 seconds up and 8 seconds down.

NB: Do NOT press record when setting times as you will record over the cue with what's on stage.

Acceptable times

0.01 One hundredth of a second

4 4 seconds

4.05 4.05 seconds

152 I minute 52 seconds

5959 **59** minutes **59** seconds

Recording Delay times

CUE 2 DELAY 5 RECORD (records the current state as Cue 2 and applies an Up/Down Delay time of 5 seconds)

CUE 8 DELAY 5 * (applies a Up/Down Delay time of 4 seconds to Cue 8 WITHOUT rerecording the state)

CUE 12 DELAY 2 / 0 * (applies a 2 second Delay time to the 'Up' portion of the cue, but leaves the Down portion to run as normal)

Recording Wait times

CUE 2 WAIT 5 RECORD (records the current state as Cue 2 and applies a Wait of 5

seconds (from the start of the cue to the start of the next cue, which

is started automatically))

Clearing Wait times

CUE 2 WAIT * Clears the Wait time from Cue 2

Recording lighting states to submasters

SUB 1 RECORD Records the current state into Submaster I (and replaces what was there before)

Submaster Times

SUB 1 TIME 4 RECORD Records the current state into Submaster I, giving it a time of 4 seconds.

Manual operation

1 THRU 3 TIME 5 @ 5 Fade channels I to 3 from current level(s) to 50% over 5 seconds.

Shut Down the desk

REPORT EXIT (softkey) twice

This is only a small fraction of the functions of this lighting desk – see the manual for more information.

JP October 2010